


SmarTROLL™ RDO Instrument






10



11



12



13

1	Site setup, site selection
2	Site photo (default shown)
3	Record/Stop button – records sensor readings every 10 seconds
4	Sensor readings – updated every 10 seconds
5	Data files – stored on the mobile device
6	Sensor calibration
7	View or email data
8	In-app purchase – access Low-Flow and Site Auto-Detection
9	Context-sensitive help