

Instruction Sheet

Nose Replacement Kit for the RDO[®] PRO and RDO[®] PRO-X Probe

Part Number 0080820

Kit Contents



1	Replacement Nose Cone
2	Installed O-ring
3	O-ring for probe body
4	Lubricant
5	Lens cloth

Replacement Procedure

1. Remove the nose cone and existing O-ring from the probe body.



1	O-ring
2	Nose Cone

2. Place a small amount of lubricant on your fingertip. Coat the entire O-ring with lubricant. Do not allow any dust or debris to get on the O-ring.
3. Place the new O-ring on the probe body.
4. Use the lens cloth to remove any lubricant from the probe and cap.
5. Place the nose cone on the probe body.